

ReadMe_Audio_NT.txt

Please use the audio driver of Windows NT for 'Creative Labs Sound Blaster 1. X, Pro, 16'.
The driver setup must be equal to the values in the BIOS Setup!

Defaults:

I/O-Address: 220h Interrupt: 5 DMA-Channel: 1 DMA-Channel (16Bit): 5
Caution: deactivate MPU401 I/O-Address!