


## ▶ Kontron RuggedClient-SKL - QUICK INSTALLATION GUIDE

Thank you for purchasing the Kontron RuggedClient-SKL industrial panel PC. This document provides information to allow you to quickly install this product.

### Packing Checklist

1. Take the RuggedClient-SKL out of the packing box and check if the unit is properly secure in the plastic bag.
2. Check the contents of the carton box: (\*: optional)
  - ▶ 1x RuggedClient-SKL
  - ▶ 1x Power Adapter
  - ▶ 1x Power Cord
  - ▶ Mounting Clamps with Screws
  - ▶ Wi-Fi Antennas\*
  - ▶ VESA Mounting Kit\*

### Rear I/O Panel



- 1 2-pin Phoenix DC-In Power Connector
- 2 2.5 mm jack DC-In Power Connector
- 3 Power Switch
- 4 DP
- 5 DVI-D
- 6 Line-In
- 7 Line-Out
- 8 Mic-In
- 9 GbE
- 10 USB 3.0
- 11 USB 2.0
- 12 RS232/422/485
- 13 RS232
- 14 PCIe x16 Add-on Card Slot (optional)