

CG2200 CONFIG & INSTALL



HOW TO CONFIGURE AND INSTALL CG2200 WITHOUT A CD/DVD DRIVE

Here is the standard procedure to burn KDA on SDcard and boot it on CG2200:

- ▶ Get latest CG2200 KDA on Kontron website. Link on the download, tools tab.
- ▶ Get UNetbootin to create a bootable SDcard from an iso file: <https://unetbootin.github.io/>
- ▶ Format the SDcard in FAT32. You can use the Format option under Windows.
- ▶ Under Unetbootin, follow those steps:
 - ▶ Press Diskimage radio button.
 - ▶ Choose ISO under list and select the newly downloaded KDA (iso file).
 - ▶ Choose the Drive corresponding to your formatted SDcard.
 - ▶ Press OK.
- ▶ When the process is done, insert the SDcard into the left side SDcard slot.
- ▶ Power up the system and boot in BIOS.
- ▶ In BIOS, under tab Boot Options, select "Generic Ultra HS-SD/MMC22.01" as Boot Option #1.
- ▶ Reboot and wait for KDA to be completely booted in graphical interface.