



886LCD-M/mITX, DRAM Module Installation


Care must be exercised when inserting the memory module on the 886LCD-M/mITX board. Please follow below guide lines.

This is only an issue for 886LCD-M/mITX boards, not for 886LCD-M/Flex or 886LCD-M/ATX boards.


DRAM insertion:

Press at the end of the DRAM module when pushing the module in place.

Press at the end of the DRAM module when pushing the module in place.



ATX Power Plug insertion:



Make sure the mITX board is supported under the ATX power connector when inserting the ATX plug to avoid poor DRAM connection.