

# » EZ3-VX3030 «



## Getting Started

SD.DT.F75-2e - January 2013

## Revision History

Publication Title:		EZ3-VX3030 Getting Started
Doc. ID:		SD.DT.F75-2e
Rev.	Brief Description of Changes	Date of Issue
0e	Initial Issue	03-2011
1e	Chapter 4 "System Revision Guide" added	04-2011
2e	Section 4.2 added Item 2	01-2013

Copyright © 2013 Kontron AG. All rights reserved. All data is for information purposes only and not guaranteed for legal purposes. Information has been carefully checked and is believed to be accurate; however, no responsibility is assumed for inaccuracies. Kontron and the Kontron logo and all other trademarks or registered trademarks are the property of their respective owners and are recognized. Specifications are subject to change without notice.

## Proprietary Note

This document contains information proprietary to Kontron. It may not be copied or transmitted by any means, disclosed to others, or stored in any retrieval system or media without the prior written consent of Kontron or one of its authorized agents.

The information contained in this document is, to the best of our knowledge, entirely correct. However, Kontron cannot accept liability for any inaccuracies or the consequences thereof, or for any liability arising from the use or application of any circuit, product, or example shown in this document.

Kontron reserves the right to change, modify, or improve this document or the product described herein, as seen fit by Kontron without further notice.

## Trademarks

This document may include names, company logos and trademarks, which are registered trademarks and, therefore, proprietary to their respective owners.

## Environmental Protection Statement

This product has been manufactured to satisfy environmental protection requirements where possible. Many of the components used (structural parts, printed circuit boards, connectors, batteries, etc.) are capable of being recycled.

Final disposition of this product after its service life must be accomplished in accordance with applicable country, state, or local laws or regulations.



**Environmental protection is a high priority with Kontron.**

**Kontron follows the DEEE/WEEE directive.**

**You are encouraged to return our products for proper disposal.**

The Waste Electrical and Electronic Equipment (WEEE) Directive aims to:

- > reduce waste arising from electrical and electronic equipment (EEE)
- > make producers of EEE responsible for the environmental impact of their products, especially when they become waste
- > encourage separate collection and subsequent treatment, reuse, recovery, recycling and sound environmental disposal of EEE
- > improve the environmental performance of all those involved during the lifecycle of EEE

## Conventions

This guide uses several types of notice: Note, Caution, ESD.



Note: this notice calls attention to important features or instructions.



Caution: this notice alert you to system damage, loss of data, or risk of personal injury.



ESD: This banner indicates an Electrostatic Sensitive Device.

All numbers are expressed in decimal, except addresses and memory or register data, which are expressed in hexadecimal. The prefix `0x` shows a hexadecimal number, following the `C` programming language convention.

The multipliers `k`, `M` and `G` have their conventional scientific and engineering meanings of  $*10^3$ ,  $*10^6$  and  $*10^9$  respectively. The only exception to this is in the description of the size of memory areas, when `K`, `M` and `G` mean  $*2^{10}$ ,  $*2^{20}$  and  $*2^{30}$  respectively.



When describing transfer rates, `k` `M` and `G` mean  $*10^3$ ,  $*10^6$  and  $*10^9$  *not*  $*2^{10}$   $*2^{20}$  and  $*2^{30}$ .

In PowerPC terminology, multiple bit fields are numbered from 0 to n, where 0 is the MSB and n is the LSB. PCI and CompactPCI terminology follows the more familiar convention that bit 0 is the LSB and n is the MSB.

Signal names ending with an asterisk (\*) or a hash (#) denote active low signals; all other signals are active high.

Signal names follow the PICMG 2.0 R3.0 CompactPCI Specification and the PCI Local Bus 2.3 Specification.

## For Your Safety

Your new Kontron product was developed and tested carefully to provide all features necessary to ensure its compliance with electrical safety requirements. It was also designed for a long fault-free life. However, the life expectancy of your product can be drastically reduced by improper treatment during unpacking and installation. Therefore, in the interest of your own safety and of the correct operation of your new Kontron product, you are requested to conform with the following guidelines.

### High Voltage Safety Instructions



**Warning!**

All operations on this device must be carried out by sufficiently skilled personnel only.



**Caution, Electric Shock!**

Before installing a not hot-swappable Kontron product into a system always ensure that your mains power is switched off. This applies also to the installation of piggybacks. Serious electrical shock hazards can exist during all installation, repair and maintenance operations with this product. Therefore, always unplug the power cable and any other cables which provide external voltages before performing work.

## Special Handling and Unpacking Instructions



### ESD Sensitive Device!

Electronic boards and their components are sensitive to static electricity. Therefore, care must be taken during all handling operations and inspections of this product, in order to ensure product integrity at all times

Do not handle this product out of its protective enclosure while it is not used for operational purposes unless it is otherwise protected.

Whenever possible, unpack or pack this product only at EOS/ESD safe work stations. Where a safe work station is not guaranteed, it is important for the user to be electrically discharged before touching the product with his/her hands or tools. This is most easily done by touching a metal part of your system housing.

It is particularly important to observe standard anti-static precautions when changing piggybacks, ROM devices, jumper settings etc. If the product contains batteries for RTC or memory backup, ensure that the board is not placed on conductive surfaces, including anti-static plastics or sponges. They can cause short circuits and damage the batteries or conductive circuits on the board.

## General Instructions on Usage

In order to maintain Kontron's product warranty, this product must not be altered or modified in any way. Changes or modifications to the device, which are not explicitly approved by Kontron and described in this manual or received from Kontron's Technical Support as a special handling instruction, will void your warranty.

This device should only be installed in or connected to systems that fulfill all necessary technical and specific environmental requirements. This applies also to the operational temperature range of the specific board version, which must not be exceeded. If batteries are present, their temperature restrictions must be taken into account.

In performing all necessary installation and application operations, please follow only the instructions supplied by the present manual.

Keep all the original packaging material for future storage or warranty shipments. If it is necessary to store or ship the board, please re-pack it as nearly as possible in the manner in which it was delivered.

Special care is necessary when handling or unpacking the product. Please consult the special handling and unpacking instruction on the previous page of this manual.

## Table Of Contents

<b>Chapter 1 - Equipment Presentation</b> .....	<b>1</b>
1.1 Overview .....	1
1.2 Ordering Information .....	2
1.3 At a Glance .....	3
1.4 Receipt of the Equipment .....	4
1.4.1 Checking the Packages .....	4
1.4.2 Unpacking .....	4
1.4.3 Content .....	5
1.5 System Identification .....	6
1.6 Introducing Front and Rear Views .....	7
1.6.1 System Type EZ3-VX3030-00 .....	7
1.7 Associated Documentation .....	9
1.8 Plug and Play with EZ3-VX3030 .....	10
1.8.1 Plug .....	10
1.8.2 Play .....	13
1.9 Health Management .....	14
<b>Chapter 2 - Software</b> .....	<b>16</b>
2.1 AMI-BIOS Firmware .....	16
2.1.1 Recovery .....	16
2.2 Linux .....	16
2.2.1 Linux System Recovery .....	16
2.3 Linux Pre-Installed System Parameters .....	17
2.3.1 Account Password .....	17
2.3.2 Disk Storage .....	17
2.3.3 Networking .....	17
2.3.4 Serial Line / Console Output .....	18
2.3.5 Linux Pre-Installed Benchmarks .....	19
<b>Chapter 3 - Technical Specifications</b> .....	<b>21</b>
3.1 Rack .....	21
3.2 VPX Backplane .....	22
<b>Chapter 4 - System Revision Guide</b> .....	<b>25</b>
4.1 How to Use the System Revision Guide Table .....	25
4.2 Revision Guide Table .....	25
4.3 Item Detailed Description .....	25

Appendix A - Technical Recommendations ..... 26

Appendix B - List of Abbreviations ..... 27

## List Of Tables

Table 1: Delivery Content ..... 5

Table 2: Mapping Table: Linux Device Name / Hardware Name ..... 11

## List Of Figures

Figure 1: EZ3-VX3030 Overview .....	2
Figure 2: Delivery Content .....	5
Figure 3: System Identification .....	6
Figure 4: Front View .....	7
Figure 5: Rear View .....	8
Figure 6: Connecting EZ3-VX3030 .....	10
Figure 7: Hardware Name of Ethernet Ports .....	11
Figure 8: SBC LEDs .....	14
Figure 9: SBC Reset Switch .....	15
Figure 10: Linux Pre-Installed System Parameters: Networking .....	17
Figure 11: Linux Pre-Installed System Parameters: Serial Line / Console Output .....	18

# Chapter 1 - Equipment Presentation

## 1.1 Overview

EZ3-VX3030 is based on the best technologies from the embedded world and is ideally suited for systems evaluation.

- > 5+ Years of Guaranteed Supply
- > 10+ Years of Hardware and Software Support
- > 3U Rackable Server
- > Fedora 12 Linux Support

EZ3-VX3030 is ready to use; its factory settings can get you to a shell prompt under Linux OS in a few seconds.

Thanks to its modular design based on standards, EZ3-VX3030 is compatible with many extensions.

## 1.2 Ordering Information

System type EZ3-VX3030-00

- |                   |                                  |                           |
|-------------------|----------------------------------|---------------------------|
| > EZ3-VX3030-00   | 3U VPX Intel® Core™ i7 Computer. |                           |
| > EZ3-VX3030-00-L | 3U VPX Intel® Core™ i7 Computer. | Linux software version.   |
| > EZ3-VX3030-00-V | 3U VPX Intel® Core™ Computer.    | VxWorks software version. |
| > EZ3-VX3030-00-W | 3U VPX Intel® Core™ Computer.    | Windows software version. |



Non contractual photography

Figure 1: EZ3-VX3030 Overview

## 1.3 At a Glance



The information displayed below applies for:

a VX3030 board Order Code: VX3030-SA22-00000  
a VX3030-RTM Order Code: PV-VX3-001

The EZ3-VX3030 system you have received may include a board, a RTM with a different order code. Please contact your Kontron representative for more information on this topic.

### » Processor

- > Intel® Core™ i7-620LE: 2.0 GHz, LV, 4 MB L3 cache

### » Memory

- > 2 GB DDR3 SDRAM Memory

### » Storage

- > Onboard mezzanine 8 GB flash USB storage

### » Connectivity (Rack Front Panel on System Type EZ3-VX3030-00 only)

- > One USB 2.0 ports
- > One Ethernet 10/100/1000BASE-T channels
- > One Serial Line (SBC Front Panel)
- > One VGA

### » Software

- > Depending on the system Order Code, Linux, VxWorks or Windows Operating System is pre-loaded on the USB User Flash at the factory.  
See Chapter 2 “Software” page 16 for details on your configuration.

### » Management

- > VX3030 Front Panel Status LEDs: System LEDs

### » Chassis Form Factor

- > 3U four-slot desktop chassis (Height: 191 mm – Width: 169.64 mm – Depth: 298.1 mm)

### » Warranty

- > 5+ years of Guaranteed Supply
- > 10+ years of Hardware and Software Support available

## 1.4 Receipt of the Equipment

### 1.4.1 Checking the Packages

Inspecting the packages and verifying their condition is the responsibility of the customer and should be carried out upon delivery.

- ▶ Inspect the cartons and check their condition:
  - ▶ no broken corners,
  - ▶ general state of the case (no rips or holes),
  - ▶ condition of the bands and the clips.
- ▶ If you wish to report any damage in transit, you should make out a full report, and also note the damage on the packing list that accompanies the equipment. Ensure that the report and the packing list are signed by yourself and also by the transport agent, and send a copy of these documents to:
  - ▶ the transport company,
  - ▶ Kontron.

### 1.4.2 Unpacking

Open the package and take out the items one by one.

Inspect each item and make a note of any possible defects (scratches, marks or blemishes, damaged cables, etc.). If necessary, make a report of any damage or defects.

Check the equipment against the packing list and report any missing items.



It is recommended that you keep the package and the anti-shock protection. This will be required if you decide to move your system or rack to a different site.

### 1.4.3 Content

Depending on the system Order Code, the EZ3-VX3030 3U VPX Intel x86 or Core i7 Computer is made of:

	EZ3-VX3030-00	EZ3-VX3030-00-L	EZ3-VX3030-00-V	EZ3-VX3030-00-W
One computer rack and associated boards	X	X	X	X
One power supply cable	X	X	X	X
One serial cable KIT-RJ12DB9	X	X	X	X
One documentation CD-ROM CDDOC	X	X	X	X
One DVD-ROM Fedora 12 PPC on VX3030	Not Applicable	X	Not Applicable	Not Applicable
One CD-ROM VxWorks 6.8 on VX3030	Not Applicable	Not Applicable	X	Not Applicable
Easy VX3030 Getting Started SD.DT.F75 (this document)	X	X	X	X
Easy VX3030 Quick Start SD.DT.F76	X	X	X	X

Table 1: Delivery Content



Figure 2: Delivery Content

## 1.5 System Identification

An identification label is available on the top side of the system.



Figure 3: System Identification

- Model: System Order Code
- Sn: Serial Number
- ECL: Engineering Change Level

## 1.6 Introducing Front and Rear Views

### 1.6.1 System Type EZ3-VX3030-00

#### » Front View




Figure 4: Front View

1. Serial Connector COM1
2. Gigabit Ethernet Connectors
3. VGA
4. USB
5. LEDs
  - ▶ 5a L1 Permanent error/Internal power OK/ Reset state/
  - ▶ 5b L2 CPLD watchdog reset timer/Normal operation mode/Factory test mode
  - ▶ 5c L3 Thermal Alert / Ethernet ETH0 Status
6. Reset Button

» RearView




Figure 5: Rear View

- 1. Power Supply Connector
- 2. AC Switch
- 3. Serial Connector COM1      Unused

» Power Supply Connector

AC connector:  
IEC320 type female plug rated 3

Pin	J1
1	Line
2	Neutral
3	Earth



## 1.7 Associated Documentation

This product is based on the VX3030 board. Therefore, the following documentations are available on the Kontron web site or on the technical documentation CD-ROM .

### » Hardware

- > VX3030 3U VPX Computing Node - User's Guide ..... CA.DT.A87
- > VX3030 - Hardware Release Notes ..... CA.DT.A88

### » Software

- > VX3030 - PBIT User's Guide ..... SD.DT.Fxx
- > VX3030 - BIOS User Manual ..... SD.DT.F81
- > Release Notes Fedora 12 on VX6060 and VX3030 ..... SD.DT.F72
- > VX3030 - VxWorks 6.8 BSP ..... SD.DT.Fxx

### » Systems

- > EZ3-VX3030-00- Quick Start ..... SD.DT.F76

## 1.8 Plug and Play with EZ3-VX3030

### 1.8.1 Plug

To connect the EZ3-VX3030 3U VPX Intel x86 or Core i7 Computer, you need to attach the following cables:

- > the Power Supply Cable (available in the delivery kit)
- > the Serial Cable KIT-RJ12DB9 (available in the delivery kit)

#### » System Type EZ3-VX3030-00




Figure 6: Connecting EZ3-VX3030



Figure 7: Hardware Name of Ethernet Ports

Linux Device Name	Hardware Name	Chassis Location
eth	ETH	Board front panel

Table 2: Mapping Table: Linux Device Name / Hardware Name

## » ON/OFF Button

The ON/OFF button is located on the rear panel of the EZ3-VX3030 Getting Started system.



## » To start the system

- ▶ Power on the main power supply module, AC Switch on the rear side of the system.

## » To stop the system

- ▶ Shutdown the OS.
- ▶ Power off the main power supply module (AC Switch on the rear side of the system).

## » Powering the system Off and On



DO NOT turn the power on while the power is cycling off. Wait a few seconds until the power has completely cycled off. Follow the same precaution for turning the power off.

Turning the power on or off before this cycle is complete can cause the voltage and temperature values programmed into the board monitoring system to be lost.

**MAKE SURE YOU FOLLOW THESE SAFETY PRECAUTIONS.**



Make sure the rack has been powered off using the ON/OFF button (on the rear panel of the rack) before unplugging the power supply cable.

## 1.8.2 Play

- Plug the system as described in section 1.8.1 “Plug” page 10.
- Power on the system
- Following screens appears:
  - ▶ AMI BIOS EFI

```
Version 2.01.1204. Copyright (C) 2010 American Megatrends, Inc.  
Press <DEL> or <F2> to enter setup. Press <F7> for BBS POPUP Menu.  
VX3030>
```

- ▶ Linux Fedora 12 (Order Code: EZ3-VX3030-00-L)

```
GRUB loading, please wait...  
lv_root rhgb iommu=off vmalloc=512MB selinux=0 acpi_enforce_resources=lax  
console=ttyS0,115200 clocksource=hpet rdblacklist=allocator rdblacklist=vxfabric  
rdblacklist=vxdma  
Linux-bzImage, setup=0x3400, size=0x377c80  
initrd /initramfs-2.6.32.14-10176.vx6060.fc12.i686.PAE.img  
Probing EDD (edd=off to disabl  
  
Initializing cgroup subsys cpuset  
Initializing cgroup subsys cpu  
Linux version 2.6.32.14-10176.vx6060.fc12.i686.PAE (root@evalpasemi) (gcc version  
4.4.2 20091027 (Red Hat 4.4.2-7) (GCC) ) #1 SMP Fri Jun 25 16:58:36 CEST 2010  
KERNEL supported cpus:  
Intel GenuineIntel  
AMD AuthenticAMD  
NSC Geode by NSC  
Cyrix CyrixInstead  
Centaur CentaurHauls  
Transmeta GenuineTMx86  
Transmeta TransmetaCPU  
UMC UMC UMC UMC  
BIOS-provided physical RAM map:  
...  
...  
...  
Starting vx6060setup [ OK ]  
Fedora release 12 (Constantine)  
Kernel 2.6.32.14-10176.vx6060.fc12.i686.PAE on an i686 (/dev/ttyS0)  
node1 login:
```

- ▶ Log in as:
  - ▶ vx3030 login: root  
password: kontron
  - or
  - ▶ vx3030 login: guest  
password: guest

## 1.9 Health Management

### » LEDs




Figure 8: SBC LEDs

- |      |               |  |
|------|---------------|--|
| ▶ L1 | <b>red</b>    | Permanent error on subsystem                                 |
|      | <b>green</b>  | Internal power OK for subsystem                              |
|      | <b>orange</b> | Reset state on subsystem                                     |
|      | <b>off</b>    | Blinking during CPLD I2C, SMI or COM                         |
| ▶ L2 | <b>red</b>    | CPLD watchdog reset timer has expired                        |
|      | <b>green</b>  | Normal operation mode  |
|      | <b>orange</b> | Factory test mode  |
|      | <b>off</b>    | Blinking during SATA activity in subsystem                   |
| ▶ L3 | <b>red</b>    | Processor hot, may trigger processor performance limitations |
|      | <b>green</b>  | Ethernet ETH connector valid on front panel                  |
|      | <b>orange</b> | Ethernet ETH link directed to backplane                      |
|      | <b>off</b>    | Blinking during ETH link activity in subsystem               |

During the system operation, LED should display:

- ▶ L1: Green,
- ▶ L2: Green,
- ▶ L3: Green.

With L2 blinking to black during SATA activity, same for L3 during ETH activity.

» Reset




Figure 9: SBC Reset Switch

## Chapter 2 - Software

### 2.1 AMI-BIOS Firmware

- AMI-BIOS release  $\geq$  11076
- Refer to “VX3030 - AMI-BIOS User Manual” Documentation (SF.DT.F81) for detailed description of AMI-BIOS Firmware.

#### 2.1.1 Recovery

- Refer to Chapter “Update AMI-BIOS Firmware” of the “VX3030 - AMI-BIOS User Manual” for more information on this topic.

### 2.2 Linux



- Fedora 12 release
- Kontron release  $\geq$  11097
- Refer to “VX3030 - Release Notes Fedora 12” Documentation for detailed description
- Refer to section 2.3 “Linux Pre-Installed System Parameters” page 17 for detailed description of the Linux system configuration.

#### 2.2.1 Linux System Recovery

- Refer to Chapter 5 “Installation” of the “VX3030 - Release Notes Fedora 12” for more information on this topic.

## 2.3 Linux Pre-Installed System Parameters

### 2.3.1 Account Password

Root account password is: **kontron**

Guest account password is: **guest**

### 2.3.2 Disk Storage

Disk storage is organised with a small **/boot** partition and a large **/** partition spanning the rest of the disk.

### 2.3.3 Networking



Figure 10: Linux Pre-Installed System Parameters: Networking

EZ3-VX3030 has one ethernet ports configured, named **eth2** under Linux Fedora 12.

**eth** (hardware name: ETH2) is configured with a private static IP of 192.168.1.1.

### 2.3.4 Serial Line / Console Output



Figure 11: Linux Pre-Installed System Parameters: Serial Line / Console Output

EZ3-VX3030 front panel serial line is managed by Linux and a login prompt is offered on it.

Characteristics of the serial line:

- ▶ Baudrate: 115200
- ▶ Parity: None
- ▶ Data Bits: 8
- ▶ Stop Bits: 1
- ▶ Flow Control: None

### 2.3.5 Linux Pre-Installed Benchmarks

One benchmark is provided with the system. It can help you to get the current performances of the system.

#### Lmbench

**lmbench** is an old fashion benchmark which consists of a suite of simple, portable benchmarks. It is interesting for results of memory bandwidth or latency.

To see the last lmbench result, change directory to `/opt/benchmarks/lmbench` and run the `make see` command.

```
[root@vx3030 ~]# cd /opt/benchmark/lmbench/
[root@vx3030 lmbench]# make see
cd results && make summary percent 2>/dev/null | more
make[1]: Entering directory `/opt/benchmark/lmbench/results'
```

```

      L M B E N C H 3 . 0   S U M M A R Y
      -----
                (Alpha software, do not distribute)

Processor, Processes - times in microseconds - smaller is better
-----
Host          OS  Mhz null null      open slct sig sig fork exec sh
              call I/O stat clos TCP  inst hndl proc proc proc
-----
vx3030      Linux 2.6.32. 2000 0.15 0.26 2.25 2.79 3.68 0.38 1.65 104. 428. 1734

Basic integer operations - times in nanoseconds - smaller is better
-----
Host          OS  intgr intgr  intgr  intgr  intgr
              bit  add   mul   div   mod
-----
vx3030      Linux 2.6.32. 0.4000 0.0100 0.1600 9.4400 9.4800

Basic float operations - times in nanoseconds - smaller is better
-----
Host          OS  float  float  float  float
              add  mul   div   bogo
-----
vx3030      Linux 2.6.32. 1.1900 1.8600 8.7300 8.7400

Basic double operations - times in nanoseconds - smaller is better
-----
Host          OS  double double double double
              add  mul   div   bogo
-----
vx3030      Linux 2.6.32. 1.0900 1.9800 8.7600 8.7200

Context switching - times in microseconds - smaller is better
-----
Host          OS  2p/0K 2p/16K 2p/64K 8p/16K 8p/64K 16p/16K 16p/64K
              ctxsw ctxsw  ctxsw ctxsw  ctxsw  ctxsw  ctxsw
-----
```

```

-----
vx3030    Linux 2.6.32. 3.7200 2.9400 3.4200 3.3800 4.2100 4.12000 4.60000

*Local* Communication latencies in microseconds - smaller is better
-----
Host      OS 2p/OK Pipe AF   UDP  RPC/  TCP  RPC/ TCP
          ctxsw  UNIX      UDP  UDP   TCP  TCP  TCP
          -----
vx3030    Linux 2.6.32. 3.720 6.899 9.03  18.6  22.9  23.3  27.7  39.

File & VM system latencies in microseconds - smaller is better
-----
Host      OS  OK File   10K File   Mmap  Prot  Page  100fd
          Create Delete Create Delete Latency Fault Fault selct
          -----
vx3030    Linux 2.6.32.  31.1 4.4166  45.7 7.9446  6215.0 0.008 1.17360 1.746

*Local* Communication bandwidths in MB/s - bigger is better
-----
Host      OS Pipe AF   TCP  File  Mmap  Bcopy  Bcopy  Mem  Mem
          UNIX  reread reread (libc) (hand) read write
          -----
vx3030    Linux 2.6.32. 2533 5607 2235 2403.4 4167.1 3235.3 2586.4 4557 4672.

Memory latencies in nanoseconds - smaller is better
(WARNING - may not be correct, check graphs)
-----
Host      OS  Mhz  L1 $  L2 $  Main mem  Rand mem  Guesses
          -----
vx3030    Linux 2.6.32. 2000 1.4330 3.6200  38.8  132.2
make[1]: Leaving directory `/opt/benchmark/lmbench/results'

```

To rerun a benchmark with the same configuration, change directory to `/opt/benchmarks/lmbench` and run the command:

```
make rerun
```

To run a benchmark with a new configuration, change directory to `/opt/benchmarks/lmbench` and run the command:

```
make result
```

## Chapter 3 - Technical Specifications

### 3.1 Rack

#### » Dimensions

- > H x W x D: 191 x 169.64 x 298.1 mm (2.45 x 6.62 x 11.63 in)

#### » Weight

- > 5.0 kg (approximate)

#### » Power Supply

- > 200W ATX industrial-power supply
- > Input range from 90 to 264 VAC (47-63 Hz)
- > Voltages:                   +3.3V / 14A  
                                  +5V / 23A  
                                  +12V / 12A

#### » Ambient Temperature

- > Operating:                 0°C to +50°C (32°F to 122°F) at sea level
- > Non-operating:           -20°C to +80°C (-4°F to 176°F)

#### » Humidity

- > 20 to 80%, non-condensing.

#### » Safety


- > TUV EN 60950 / UL 60950

## 3.2 VPX Backplane

### » Key Figures

- > Compliant to VITA 46.0 baseline specification
- > Supports VITA 46.4 Full mesh x1 PCI Express
- > Supports VITA 46.10 with RTM connectors
- > 3U, 4 slots, Full Mesh configuration
- > M4 screws and ATX 24 poles connector for powerentry
- > PCB size TBD mm x 120.7 mm x 5.4 mm
- > 4 HP from slot to slot (20.32 mm)
- > System Management Interface on the backplane (I<sup>2</sup>C1, I<sup>2</sup>C2)
- > Flexible keying and alignment mechanism
- > with JTAG connector on first slot
- > with geographical address pin
- > Reference clock
- > Non-Volatile Memory Read Only signal set by Jumper X5. Vbat extrnal or connected to 3.3 AUX.
- > System Reset
- > P1 Reserved Signals
- > Operating temperature:
  - 40°C
  - +85°C
- > Storage temperature:
  - 55°C
  - +85°C
- > Flammability rating:
  - UL94-V0

### » Topology: Full Mesh x1



## » Current Capability


(By using ATX connector, see values in brackets)

> +12V	40A (10A)
> +3.3V	80A (20A)
> +5V	80A (25A)
> -12V_AUX	5A
> +12V_AUX	5A
> +3.3V_AUX	5A

## » System Management IPMB (I<sup>2</sup>C1, I<sup>2</sup>C2 connector)

There are 2 connectors (5 poles) for system management I<sup>2</sup>C1, I<sup>2</sup>C2

I <sup>2</sup> C1	Signal	I <sup>2</sup> C2	Signal
1	SCL1	1	SCL2
2	GND	2	GND
3	SDA1	3	SDA2
4	+3.3V_AUX	4	+3.3V_AUX
5		5	



## » VBAT (X5 connector)

Normally a battery voltage with approximately 3V is available at Pin VBAT of connector VPX-J1. The voltage is externally accessible with connector X5. The battery should be connected to pin1 and 2 or internally using 3.3V\_AUX by closing a Jumper between pin 2 and 3.

X5	Signal
1	GND
2	VBAT
3	+3.3V_AUX

## » NVMRO (BR1 jumper)

If Jumper BR1 is closed NVRMO is set to memory writable


BR1	Signal
1	NVMRO
2	GND



» JTAG (connector XJT1)

For test and programming a JTAG connector (6-poles) is implemented (XJT1)


XJT1	Signal
1	GND
2	TCK
3	TMS
4	TRST-
5	TDI
6	TDO



» Power Connection (X1 or M4 screw)

The main operating voltages and GND are supplied with M4 screw terminals or connector X1 (fits to ATX connector without locking mechanism). The auxiliary operating voltages are supplied via M3 screw terminals. Optimal daughter board supply and trouble-free operation are ensured by the arrangement of the feed modules on the backplane.

X1	Signal	Signal	X1
1	+3.3V	+3.3V	13
2	+3.3V	-12V	14
3	GND	GND	15
4	+5V	PS_ON	16
5	GND	GND	17
6	+5V	GND	18
7	GND	GND	19
8	PWR_OK	Res	20
9	+5VSB	+5V	21
10	+12V	+5V	22
11	+12V	+5V	23
12	+3.3V	GND	24



If Jumper X6 is closed, ATX power supply starts automatically.

# Chapter 4 - System Revision Guide

## 4.1 How to Use the System Revision Guide Table

1. Find the E.C. Level associated to your system as described in the Chapter 1.5 “Board Identification” page 6.
2. Find the column associated to this E.C. Level in the table.
3. Check for a specific item in the table lines:
  - 3.1. A x (cross) in the E.C. Level column indicates that this item applies to this E.C. Level.
  - 3.2. No x (cross) in the E.C. Level column indicates that this item does not apply to this E.C. Level.



Each item is fully described in section 4.3 “Item Detailed Description” page 25.

## 4.2 Revision Guide Table

Item	Description	E.C. Level					
		00000	00001				
1	Initial system E.C. Level	X					
2	System software ID11129		X				

## 4.3 Item Detailed Description



Each item applies only to a specific group of E.C. Levels. Refer to the table available in section 4.2 “Revision Guide” page 25 to find the specific E.C. Levels associated to a specific item.

---

### Item # 1 Initial system E.C. Level

Tested with Board revision ECL1001, BIOS ID10351 and system software ID11010.

---

### Item # 2 System software ID11129

System Software Evolution ID11129.

---

## Appendix A - Technical Recommendations



### Recommendation

Avoid connecting your rack on the same circuit as any electrical equipment that does not have a noise suppressor, and can produce transient phenomena.

It is preferable to install a separate power line directly from the main electrical network.

All the system components (peripheral rack, printer, etc.) must be connected directly to the main electrical network.



### Power Supply

Check the correct input voltage prior applying power to the unit. Refer to Chapter 3 "Technical Specifications", section "Power Supply".



### Electrical safety

To prevent electrical accidents that could damage your equipment and threaten user safety, adhere to the regulations and standards recommended in the IEC publication 364 (International Electronic Commission) and the French standard NFC 15-100.



### Electrical Damage

Avoid connecting cables to the front panel application connectors while functioning. Voltage discharge may damage the inserted boards I/O devices or the power supply.



### Fire safety

Fire extinguishers, type CO<sub>2</sub>, should be installed in the work area, close to the rack.



### User Safety

All fans are externally protected with proper finger guard grids. User should avoid touching any fan part with his fingers.



**DO NOT** turn the power on while the power is cycling off. Wait a few seconds until the power has completely cycled off. Follow the same precaution for turning the power off.

Turning the power on or off before this cycle is complete can cause the voltage and temperature values programmed into the board monitoring system to be lost.

**MAKE SURE YOU FOLLOW THESE SAFETY PRECAUTIONS.**



Make sure the rack has been powered off using the ON/OFF button (on the rear panel of the rack) before unplugging the power supply cable.



It is strongly recommended to use an antistatic wrist strap and a conductive foam pad when you install or upgrade your system to prevent the accumulation of electrostatic charges.



Avoid touching areas of integrated circuitry; static discharge can damage circuits.

## Appendix B - List of Abbreviations

AC	Alternating Current
BSP	Board Support Package
DC	Direct Current
EMC	Electro-Magnetic Compatibility
ESD	Electrostatic Sensitive Device
LED	Light Emitting Diode
MTBF	Mean Time Between Failures
OS	Operating System
PMC	PCI Mezzanine Card
RTM	Rear Transition Module
SBC	Single Board Computer
SDRAM	Synchronous DRAM. A type of dynamic RAM memory chip.
U	The U is a standard unit of height measurement (e.g. 1U). One U is 4.445 centimetres (1.75 inches).
USB	Universal Serial Bus.
WEEE	Waste Electrical and Electronics Equipment
XMC	Express Mezzanine Card (VITA)

**MAILING ADDRESS**

Kontron Modular Computers S.A.S.  
150 rue Marcelin Berthelot - BP 244  
ZI TOULON EST  
83078 TOULON CEDEX - France

**TELEPHONE AND E-MAIL**

+33 (0) 4 98 16 34 00  
sales@kontron.com  
support-kom-sa@kontron.com

For further information about other Kontron products, please visit our Internet web site:  
[www.kontron.com](http://www.kontron.com).